



## ScareCrow<sup>®</sup> automatic outdoor animal deterrent

**Keep animals away from your pond or garden with a harmless blast of water.**

Protect your yard, fruit trees, vegetables, flowers and water features from hungry or destructive animal intruders. The ScareCrow<sup>®</sup> motion-activated sprinkler automatically detects deer, racoons, heron, dogs and more as they approach, and repels them with a short but startling burst of water. The sudden noise, movement and spray scares animals away, teaching them to avoid the area in future.

### **ScareCrow**

- works day and night without chemicals or unsightly barriers
- can be linked to other ScareCrows to form an effective water barrier
- conserves water - uses just 2 to 3 cups per deterrence
- operates for up to six months on a single nine-volt battery
- one scarecrow covers approximately 1200 sq. ft.

## How & Why it Works



Using the ScareCrow is easy. Simply attach a standard garden hose to its base, set the ScareCrow in the ground in the area you want to protect, and then turn on the water. Once you switch the unit on, it is ready to go.

### **How does it work?**

The ScareCrow uses a combination of sudden noise, unexpected movement, and a startling blast of water to create a memorable and unpleasant experience for the trespasser.


The animal immediately associates this unpleasant experience with the location, and to avoid similar surprises, learns to avoid the area. If an animal chooses to return, the ScareCrow will be waiting.

While a human may flee several steps after activating a ScareCrow, animals are typically affected to a much greater degree. In most cases they run much farther, and stay away longer. Because the unit only triggers when the animal moves, its behaviour is difficult for animals to anticipate, making it a very effective deterrent.

## Specifications



The ScareCrow motion-activated sprinkler is constructed of durable, high-quality materials, and has been designed to provide many years of reliable service.




### Sensitivity Settings

Distance you wish to detect animal

Animal Size	10ft.	20ft.	30ft.
Small	6-7	7-9*	
Medium	3-4	5-6	7-9
Large	2-3	4-5	6-9

\*Some small animals might not be seen at this distance

### Range Diagram



For more information please contact us at [scarecrow@easytek.co.nz](mailto:scarecrow@easytek.co.nz)